ergotron® moving you forward

StyleView Sit-Stand Combo Arm

Comfortable documentation

 Work sitting or standing with 20" (50,8 cm) of height adjustment

Personalized fit

 Includes 5.1" (13 cm) of LCD adjustment, plus up to 43" (109,22 cm) of LCD and keyboard extension

Ergonomic set-up

Back-tilt keyboard tray protects wrists from pain or injury

Infection control

 Offers easy-to-clean features and antimicrobial-treated surfaces and wrist rest

Save space

• Fold the arm out of the way and stow the keyboard tray when not in use

Clean look

Cables stay hidden and organized for easy cleaning

STYLEVIEW[™]

• Includes 5-year warranty



WORKSURFACE WITH PULL-OUT KEYBOARD TRAY FACILITATES CAREGIVER WORKFLOW

The StyleView Sit-Stand Combo Arm holds a monitor, bar-code scanner, keyboard, wrist rest and mouse on the same arm, providing easy, single-motion height adjustment.

Arm extends and retracts; fold back out of the way when not in use. Work sitting or standing with the arm's ergonomic 25" (64 cm) LCD height adjustment range. A unique cable management system conceals and organizes cords, making cleaning easy.

STYLEVIEW[™]

	StyleView Sit-Stand Combo Arm with Worksurface	StyleView Sit-Stand Combo Arm	StyleView Sit-Stand Combo System with Worksurface	StyleView Sit-Stand Combo System
Part # (color)	45-260-026 (polished aluminum) 45-260-216 (white)	45-266-026 (polished aluminum) 45-266-216 (white)	Medium CPU holder and wall track: 45-270-026 (polished aluminum) Small CPU holder and wall track: 45-272-026 (polished aluminum) Medium CPU holder and wall track: 45-270-216 (white) Small CPU holder and wall track: 45-272-216 (white)	Medium CPU holder and wall track: 45-271-026 (polished aluminum) Small CPU holder and wall track: 45-273-026 (polished aluminum) Medium CPU holder and wall track: 45-271-216 (white) Small CPU holder and wall track: 45-273-216 (white)
	Optional extender arm 45-261-026 (polished aluminum) 45-261-216 (white)	Optional extender arm 45-261-026 (polished aluminum) 45-261-216 (white)	Optional extender arm 45-261-026 (polished aluminum) 45-261-216 (white)	Optional extender arm 45-261-026 (polished aluminum) 45-261-216 (white)
Typical LCD Size	≤ 24″			
LCD SIZE IS APPROXIMATION. DIMENSION IS DIAGONAL MEASUREMENT OF SCREEN. LCD SIZE MAY BE EXCEEDED AS LONG AS SCREEN WEIGHT DOES NOT EXCEED MAXIMUM WEIGHT CAPACITY OF THE MOUNT.				
Weight Capacity	≤ 32 lbs (≤ 14,5 kg)*	≤ 2 9 lbs (≤ 13,2 kg)*	≤ 32 lbs (≤ 1 4,5 kg)*	≤ 29 lbs (≤ 13,2 kg)*
Lift	63.5 cm*			
Tilt	LCD 30° ↑25° / ↓5°			
Pan	360°			
Rotation	90°	360°	90°	360°
VESA	MIS-D			
Extension	Adds additional 17" (43 cm) extension from the wall			
Product Weight	32 lbs (14.6 kg)	24.7 lbs (11.2 kg)	41 lbs (19 kg)	38.4 lbs (17.5 kg)
Shipping Dimensions	26.7″ x 26.3″ x 10.6″ (67,7 x 66,8 x 27 cm)	25.5" x 22.1" x 11.1" (64,8 x 56,1 x 28,2 cm)	37.1" x 26.1" x 10" (94,2 x 66,2 x 25,4 cm)	37.1″ x 22.1″ x 11.1″ (94,2 x 56,1 x 28,2 cm)
Shipping Weight	39 lbs (17,7 kg)	31 lbs (14,1 kg)	51 lbs (23 kg)	47 lbs (21,4 kg)
Warranty	5 years			

*See website for details

- 1 Patented Constant Force[™] lift-and-pivot motion technology provides premium 25" (63,5 cm) LCD height adjust-ment, portrait-to-landscape rotation and 30° tilt
- 2 Durable, easy-to-clean exterior composed of aluminum and high-grade plastic
- 3 Integrated mouse and barcode scanner holder provide easy access
- 4 Fold-down worksurface/keyboard tray to support workflow needs Worksurface is 22.75"W x 10.6"D (57,8 x 26,9 cm) Keyboard tray is 18.6"W x 9"D (47,2 x 22,8 cm)
- 5 Ergonomic back-tilt keyboard tray ensures wrists remain in a neutral position during data entry. Includes slide-out mouse tray
- 6 Extend LCD and keyboard up to 43" (109 cm) from wall; fold equipment back out of the way when not in use. With worksurface in storage position, system depth is as little as 8" (20,3 cm). With keyboard in storage position, system depth is as little as 12" (30,5 cm)
- 7 Clean, concealed and neat routing of cables
- 8 Optional Extender Arm increases range of motion for even greater reach



APAC: apaccustomerservice@ergotron.com LATAM Sales: Mexico / +1.800.681.1820 / info.latam@ergotron.com

Custom: custom@ergotron.com

© Ergotron, Inc. 04.20.2021 Literature made in the U.S.A. Content subject to change. Ergotron devices are not intended to cure, treat, mitigate or prevent any disease. Patent information available at www.ergotron.com/patents. WorkFit, StyleView, LearnFit, Neo-Flex, PowerShuttle, LiFeKinnex, CareFit and eKinnex are trademarks of Ergotron.







